



**Step 1**

Insert all bolts and cams.

**Step 2**

Insert top and bottom panels to one side of rack, then the other, and tighten cams.

**Step 3**

Attach legs to bottom of rack, one inch from ends.

**Step 4**

Loosen one side of rack at the top, and insert extrusion so that its lip falls into the groove of the rack board, then tightening afterwards.

**Step 5**

Using the four long screws, secure extrusion by screwing it (from the inside) into the pre-drilled holes in the sides of the rack.

**Step 6**

Using the three short screws, secure top of extrusion, by screwing the top into the back of the rack.

**Step 7**

Place the L-Divider.